

QUIET KIT

Installation
instructions

FOR BATHTUB

MULTI-LANGUAGE



Ready to install soundproofing solution

Kit contents



| items | quantity | function |
|-------------------------|----------|--|
| big strong dampers | | reduces vibration and adds rigidity thanks to the metal foil. This shape is used on the largest, flattest and most vibration-loaded parts of the object. |
| triangle strong dampers | | removes vibration and adds framing to the object at all corners. Stabilises the surface. |
| hotter | | effectively retains heat and removes residual noise thanks to the red mastic. Keeps and supports heat, promotes faster heating of the object. |
| wave memory foam | | increased absorption area thanks to the wavy porous design, absorbs noise in the fine-cell structure. Thicker material with increased efficiency. |
| gloves | | helps keep your hands safe and clean. |

IMPORTANT SAFETY INFORMATION



Always wear protective gear when installing



Keep away from open flames, sparks or high heat



Watch for sharp foil & film edges — risk of cuts



Use only as intended



Ventilate after installation (temporary mild odour)




Work with pleasure and without haste

- 1**  **PREPARATION**
Put on protective gloves and clean the surface where the material will be installed

**QUIET
KIT**

- 2** **INSTALL STRONG DAMPERS**
Big, triangle and local



Fit **6** big strong dampers to the underside of the bathtub bottom and **6** to the sides of the bathtub



Use the strong triangle dampers to the corners of the bathtub


3




**INSTALL
THERMAL RETAINERS**

apply the hotters to the bottom of the shower tray as a second layer, on top of the big dampers

**keep warm
for your comfort**



4



TREAT THE SIPHON WITH ABSORBER
Apply the wave memory foam material to the siphon


FINAL RESULT



SOLID
SILENT TUB



SUPERIOR
HEAT KEEPING



quiet-kits.com

Thank you for choosing



Learn more about us